


# User Manual

## SOLAR INVERTER **3KW**



# Table Of Contents

<b>ABOUT THIS MANUAL</b>	<b>1</b>
Purpose	1
Scope	1
<b>SAFETY INSTRUCTIONS</b>	<b>1</b>
<b>INTRODUCTION</b>	<b>2</b>
Features	2
Basic System Architecture	2
Product Overview	3
<b>INSTALLATION</b>	<b>4</b>
Unpacking and Inspection	4
Preparation	4
Mounting the Unit	4
Battery Connection	5
AC Input/Output Connection	7
PV Connection	9
Final Assembly	11
Remote Display Panel Installation	11
Communication Connection	12
Dry Contact Signal	12
<b>OPERATION</b>	<b>12</b>
Power ON/OFF	12
Operation and Display Panel	13
LCD Display Icons	15
LCD Setting	21
Display Setting	25
Operating Mode Description	27
Battery Equalization Description	29
Fault Reference Code	30
Warning Indicator	30
<b>SPECIFICATIONS</b>	<b>31</b>
Table 1 Line Mode Specifications	31
Table 2 Inverter Mode Specifications	32
Table 3 Charge Mode Specifications	33
Table 4 General Specifications	33
<b>TROUBLE SHOOTING</b>	<b>34</b>
<b>Appendix: Approximate Back-up Time Table</b>	<b>36</b>

## ABOUT THIS MANUAL

### Purpose

This manual describes the assembly, installation, operation and troubleshooting of this unit. Please read this manual carefully before installations and operations. Keep this manual for future reference.

### Scope

This manual provides safety and installation guidelines as well as information on tools and wiring.

## SAFETY INSTRUCTIONS



**WARNING:** This chapter contains important safety and operating instructions. Read and keep this manual for future reference.

1. Before using the unit, read all instructions and cautionary markings on the unit, the batteries and all appropriate sections of this manual.
2. **CAUTION** --To reduce risk of injury, charge only deep-cycle lead acid type rechargeable batteries. Other types of batteries may burst, causing personal injury and damage.
3. Do not disassemble the unit. Take it to a qualified service center when service or repair is required. Incorrect re-assembly may result in a risk of electric shock or fire.
4. To reduce risk of electric shock, disconnect all wirings before attempting any maintenance or cleaning. Turning off the unit will not reduce this risk.
5. **CAUTION** – Only qualified personnel can install this device with battery.
6. **NEVER** charge a frozen battery.
7. For optimum operation of this inverter/charger, please follow required spec to select appropriate cable size. It's very important to correctly operate this inverter/charger.
8. Be very cautious when working with metal tools on or around batteries. A potential risk exists to drop a tool to spark or short circuit batteries or other electrical parts and could cause an explosion.
9. Please strictly follow installation procedure when you want to disconnect AC or DC terminals. Please refer to INSTALLATION section of this manual for the details.
10. One piece of 150A fuse is provided as over-current protection for the battery supply.
11. **GROUNDING INSTRUCTIONS** -This inverter/charger should be connected to a permanent grounded wiring system. Be sure to comply with local requirements and regulation to install this inverter.
12. **NEVER** cause AC output and DC input short circuited. Do NOT connect to the mains when DC input short circuits.
13. **Warning!!** Only qualified service persons are able to service this device. If errors still persist after following troubleshooting table, please send this inverter/charger back to local dealer or service center for maintenance.
14. **WARNING:** Because this inverter is non-isolated, only three types of PV modules are acceptable: single crystalline, poly crystalline with class A-rated and CIGS modules. To avoid any malfunction, do not connect any PV modules with possible current leakage to the inverter. For example, grounded PV modules will cause current leakage to the inverter. When using CIGS modules, please be sure NO grounding.
15. **CAUTION:** It's requested to use PV junction box with surge protection. Otherwise, it will cause damage on inverter when lightning occurs on PV modules.

## INTRODUCTION

This is a multi-function inverter/charger, combining functions of inverter, solar charger and battery charger to offer uninterruptible power support with portable size. Its comprehensive LCD display offers user-configurable and easy-accessible button operation such as battery charging current, AC/solar charger priority, and acceptable input voltage based on different applications.

### Features

- Pure sine wave inverter
- Configurable input voltage range for home appliances and personal computers via LCD setting
- Configurable battery charging current based on applications via LCD setting
- Configurable AC/Solar Charger priority via LCD setting
- Compatible to mains voltage or generator power
- Auto restart while AC is recovering
- Overload/ Over temperature/ short circuit protection
- Smart battery charger design for optimized battery performance
- Cold start function
- Removable LCD control module
- Reversed communication port for BMS (RS485, CAN-BUS, RS232)
- Build-in Bluetooth for mobile monitoring (Requires App), OTG USB function, dusk filters
- Configurable AC/PV Output usage timer and prioritization

### Basic System Architecture

The following illustration shows basic application for this inverter/charger. It also includes following devices to have a complete running system:

- Generator or Utility.
- PV modules

Consult with your system integrator for other possible system architectures depending on your requirements.

This inverter can power all kinds of appliances in home or office environment, including motor-type appliances such as tube light, fan, refrigerator and air conditioner.






Figure 1 Hybrid Power System

One detection device needs be connected between the PV + and PV- & the ground, to ensure leakage current between PV + and PV- & the ground is less than 30mA.  
Isolation transformer Specs. : 10KW—220:220V 60\*100 single phase Isolation transformer.

## Product Overview



- |   |                     |
|---|---------------------|
| 1. LCD display  | 7. AC input         |
| 2. Status indicator   | 8. AC output        |
| 3. Charging indicator   | 9. PV input         |
| 4. Fault indicator  | 10. Battery input   |
| 5. Function buttons   | 11. Circuit breaker |
| 6. Power on/off switch  |                     |
| 12. Dry contact   |                     |
| 13. USB communication port  |                     |
| 14. BMS Communication port: CAN and RS232 or RS485  |                     |
| 15. RS-232 communication port   |                     |
| 16. LED indicators for USB function setting/ Output source priority timer / Charger source priority setting |                     |



## INSTALLATION


### Unpacking and Inspection

Before installation, please inspect the unit. Be sure that nothing inside the package is damaged. You should have received the following items inside of package:

- The unit x 1
- User manual x 1
- RS232 Communication cable x 1

### Preparation


Before connecting all wirings, please take off bottom cover by removing two screws as shown below. Remove the cables from the cover.



### Mounting the Unit


Consider the following points before selecting where to install:

- Do not mount the inverter on flammable construction materials.
- Mount on a solid surface
- Install this inverter at eye level in order to allow the LCD display to be read at all times.
- For proper air circulation to dissipate heat, allow a clearance of approx. 20 cm to the side and approx. 50 cm above and below the unit.
- The ambient temperature should be between 0°C and 55°C to ensure optimal operation.
- The recommended installation position is to be adhered to the wall vertically.
- Be sure to keep other objects and surfaces as shown in the diagram to guarantee sufficient heat dissipation and to have enough space for removing wires.



**SUITABLE FOR MOUNTING ON CONCRETE OR OTHER NON-COMBUSTIBLE SURFACE ONLY.**

Install the unit by screwing two screws. It's recommended to use M4 or M5 screws.



### Battery Connection

**CAUTION:** For safety operation and regulation compliance, it's requested to install a separate DC over-current protector or disconnect device between battery and inverter. It may not be requested to have a disconnect device in some applications, however, it's still requested to have over-current protection installed. Please refer to typical amperage in below table as required fuse or breaker size.

**WARNING!** All wiring must be performed by a qualified personnel.  
**WARNING!** It's very important for system safety and efficient operation to use appropriate cable for battery connection. To reduce risk of injury, please use the proper recommended cable as below.

**Ring terminal:**




Recommended battery cable size:


Model	Typical Amperage	Wire Size	Cable (mm <sup>2</sup> )	Ring Terminal Dimensions		Torque value
				D (mm)	L (mm)	
3KW	148A	1 x 2AWG	38	8.4	39.2	5 Nm

Please follow below steps to implement battery connection:

1. Assemble battery ring terminal based on recommended battery cable and terminal size.
2. Connect all battery packs as units requires. It's suggested to connect at least 100Ah capacity battery for 3KW model and at least 200Ah capacity battery for 5KW model.



3. Insert the ring terminal of battery cable flatly into battery connector of inverter and make sure the bolts are tightened with torque of 5 Nm. Make sure polarity at both the battery and the inverter/charge is correctly connected and ring terminals are tightly screwed to the battery terminals.



**WARNING: Shock Hazard**

Installation must be performed with care due to high battery voltage in series.



**CAUTION!!** Do not place anything between the flat part of the inverter terminal and the ring terminal. Otherwise, overheating may occur.

**CAUTION!!** Do not apply anti-oxidant substance on the terminals before terminals are connected tightly.

**CAUTION!!** Before making the final DC connection or closing DC breaker/disconnector, be sure positive (+) must be connected to positive (+) and negative (-) must be connected to negative (-).

## AC Input/Output Connection

**CAUTION!!** Before connecting to AC input power source, please install a separate AC breaker between inverter and AC input power source. This will ensure the inverter can be securely disconnected during maintenance and fully protected from over current of AC input. The recommended spec of AC breaker is 32A for 3KW and 50A for 5KW.

**CAUTION!!** There are two terminal blocks with "IN" and "OUT" markings. Please do NOT mis-connect input and output connectors.

**WARNING!** All wiring must be performed by a qualified personnel.

**WARNING!** It's very important for system safety and efficient operation to use appropriate cable for AC input connection. To reduce risk of injury, please use the proper recommended cable size as below.

### Suggested cable requirement for AC wires

Model	Gauge	Cable(mm <sup>2</sup> )	Torque value
3 KW	12AWG	4	1.2 Nm


### Please follow below steps to implement AC input/output connection:

1. Before making AC input/output connection, be sure to open DC protector or disconnecter first.
2. Remove insulation sleeve 10mm for six conductors. And shorten phase L and neutral conductor N 3 mm.
3. Insert AC input wires according to polarities indicated on terminal block and tighten the terminal screws. Be sure to connect PE protective conductor (⊕) first.

⊕ → Ground (yellow-green)

L → LINE (brown or black)

N → Neutral (blue)



**WARNING:**

Be sure that AC power source is disconnected before attempting to hardwire it to the unit.

4. Then, insert AC output wires according to polarities indicated on terminal block and tighten terminal screws.


Be sure to connect PE protective conductor (⊕) first.

⊕ → Ground (yellow-green)

L → LINE (brown or black)

N → Neutral (blue)

5. Make sure the wires are securely connected.





**CAUTION:** Appliances such as air conditioner are required at least 2~3 minutes to restart because it's required to have enough time to balance refrigerant gas inside of circuits. If a power shortage occurs and recovers in a short time, it will cause damage to your connected appliances. To prevent this kind of damage, please check manufacturer of air conditioner if it's equipped with time-delay function before installation. Otherwise, this inverter/charger will trig overload fault and cut off output to protect your appliance but sometimes it still causes internal damage to the air conditioner.

## PV Connection

**CAUTION:** Before connecting to PV modules, please install separately a DC circuit breaker between inverter and PV modules.

**WARNING!** It's very important for system safety and efficient operation to use appropriate cable for PV module connection. To reduce risk of injury, please use the proper recommend cable size as below.

Model	Wire Size	Cable(mm <sup>2</sup> )	Torque value(max)
3KW	1 x 12AWG	4	0.8 Nm

**WARNING:** Because this inverter is non-isolated, only three types of PV modules are acceptable: single crystalline, poly crystalline with class A-rated and CIGS modules. To avoid any malfunction, do not connect any PV modules with possible current leakage to the inverter. For example, grounded PV modules will cause current leakage to the inverter. When using CIGS modules, please be sure NO grounding.

**CAUTION:** It's requested to use PV junction box with surge protection. Otherwise, it will cause damage on inverter when lightning occurs on PV modules.

### PV Module Selection:

When selecting proper PV modules, please be sure to consider below parameters:

1. Open circuit Voltage (Voc) of PV modules not exceeds max. PV array open circuit voltage of inverter.
2. Open circuit Voltage (Voc) of PV modules should be higher than min. battery voltage.

INVERTER MODEL	3KW
Max. PV Array Open Circuit Voltage	500Vdc
PV Array MPPT Voltage Range	120Vdc~450Vdc

Take 250Wp PV module as an example. After considering above two parameters, the recommended module configurations are listed as below table.

Solar Panel Spec (reference)	SOLAR INPUT	Qty of panels	Total input power
	(Min in serial:6 pcs,max.in serial:12 pcs)		
-250Wp	6 pcs in serial	6 pcs	1500W
-Vmp:30.1Vdc	8 pcs in serial	8 pcs	2000W
-Imp:8.3A	12 pcs in serial	12 pcs	3000W
-Voc:37.7Vdc	8 pieces in serial and 2 sets in parallel	16 pcs	4000W
-Isc:8.4A			
-Cells:60			

### PV Module Wire Connection


Please follow below steps to implement PV module connection:

1. Remove insulation sleeve 7 mm for positive and negative conductors.
2. Suggest to put bootlace ferrules on the end of positive and negative wires with a proper crimping tool.




3. Check correct polarity of wire connection from PV modules and PV input connectors. Then, connect positive pole (+) of connection wire to positive pole (+) of PV input connector. Connect negative pole (-) of connection wire to negative pole (-) of PV input connector. Screw two wires tightly in clockwise direction.

Recommended tool: 4mm blade screwdriver




### Final Assembly

After connecting all wirings, please put bottom cover back by screwing two screws as shown below.



Connect LCD panel to the inverter with an optional RJ45 communication cable as below chart.




## Communication Connection

### Serial Connection

Please use supplied communication cable to connect to inverter and PC. Insert bundled CD into a computer and follow on-screen instruction to install the monitoring software. For the detailed software operation, please check user manual of software inside of CD.


### Wifi Connection

This series is built in Wifi technology. It allows wireless communication up to 6~7m in an open space.




## Dry Contact Signal

There is one dry contact (3A/250VAC) available on the rear panel. It could be used to deliver signal to external device when battery voltage reaches warning level.

Unit Status	Condition		Dry contact port: 	
			NC & C	NO & C
Power Off	Unit is off and no output is powered.		Close	Open
Power On	Output is powered from Utility.		Close	Open
	Output is powered from Battery power or Solar energy.	Program 01 set as USB (utility first)	Open	Close
		Battery voltage < Low DC warning voltage	Open	Close
	Program 01 is set as SBU (SBU priority) or SUB (solar first)	Battery voltage > Setting value in Program 13 or battery charging reaches floating stage	Close	Open
		Battery voltage < Setting value in Program 12	Open	Close
		Battery voltage > Setting value in Program 13 or battery charging reaches floating stage	Close	Open

## OPERATION


### Power ON/OFF





Once the unit has been properly installed and the batteries are connected well, simply press On/Off switch (located on the display panel) to turn on the unit.

## Operation and Display Panel

The operation and display panel, shown in below chart, is on the front panel of the inverter. It includes six indicators, six function keys, on/off switch and a LCD display, indicating the operating status and input/output power information.










### Indicators


LED Indicator		Color	Solid/Flashing	Messages
Setting LED 1		Green	Solid On	Output powered by utility
Setting LED 2		Green	Solid On	Output powered by PV
Setting LED 3		Green	Solid On	Output powered by battery
Status indicators	 <b>AC INV</b>	Green	Solid On	Output is available in bypass mode
			Flashing	Output is powered by battery in inverter mode
	 <b>CHG</b>	Green	Solid On	Battery is fully charged
			Flashing	Battery is charging
	<b>FAULT</b>	Red	Solid On	Fault mode
			Flashing	Warning mode










## Function Keys

Function Key	Description
	ESC
	USB function setting
	Timer setting for the Output source priority
	Timer setting for the Charger source priority
	Up
	Down
	Enter

## LCD Display Icons



Icon	Function description
<b>Input Source Information</b>	
	Indicates the AC input.
	Indicates the PV input
	Indicate input voltage, input frequency, PV voltage, charger current, charger power, battery voltage.
<b>Configuration Program and Fault Information</b>	
	Indicates the setting programs.
	Indicates the warning and fault codes. Warning:  flashing with warning code. Fault:  lighting with fault code

## Output Information

OUTPUTBATTEMP  
888  
kW  
VA  
Hz

Indicate output voltage, output frequency, load percent, load in VA, load in Watt and discharging current.

## Battery Information









BATT 

Indicates battery level by 0-24%, 25-49%, 50-74% and 75-100% in battery mode and charging status in line mode.







In AC mode, it will present battery charging status.











Status	Battery voltage	LCD Display
Constant Current mode / Constant Voltage mode	<2V/cell	4 bars will flash in turns.
	2 ~ 2.083V/cell	Bottom bar will be on and the other three bars will flash in turns.
	2.083 ~ 2.167V/cell	Bottom two bars will be on and the other two bars will flash in turns.
	> 2.167 V/cell	Bottom three bars will be on and the top bar will flash.
Floating mode. Batteries are fully charged.		4 bars will be on.

In battery mode, it will present battery capacity.

Load Percentage	Battery Voltage	LCD Display
Load > 50%	<1.85V/cell	 LOW BATT
	1.85 ~ 1.933V/cell	 BATT
	1.933 ~ 2.017V/cell	 BATT
	> 2.017 V/cell	 BATT
Load < 50%	<1.892V/cell	 LOW BATT
	1.892 ~ 1.975V/cell	 BATT
	1.975 ~ 2.058V/cell	 BATT
	> 2.058 V/cell	 BATT






## Load Information

-----OVERLOAD	Indicates overload	
	Indicates the load level by 0-24%, 25-49%, 50-74% and 75-100%	
	0%~24%	25%~49%
	 LOAD	 LOAD
	50%-74%	75%~100%
	 LOAD	 LOAD

Mode Operation Information	
	Indicates unit connects to the mains
	Indicates unit connects to the PV panel
	Indicates load is supplied by utility power
	Indicates the utility charger circuit is working
	Indicates the solar charger circuit is working
	Indicates the DC/AC inverter circuit is working
	Indicates unit alarm is disabled
	Indicates Bluetooth/Wifi is connected
	Indicates USB disk is connected
	Time display page

## LCD Setting

### General Setting

After pressin and holding'  'button for 3 seconds,the unit will enter setting mode. press'  'or'  'Button to select setting programs.And then,press'  'button to confirm the selection or'  'button to exit.

### Setting Programs:

Program	Description	Selectable option
00	Exit setting mode	Escape 00 * ESC

Program	Description	Selectable option	
01	Output source priority: To configure load power source priority	Utility first (default) 01 * USB	Utility will provide power to the loads as first priority. Solar and battery energy will provide power to the loads only when utility power is not available.
		Solar first 01 * SUB	Solar energy provides power to the loads as first priority. If solar energy is not sufficient to power all connected loads, utility will supply power the loads at the same time. If there is no utility power and the solar is insufficient, battery will power the load.
		SBU priority 01 * SBU	Solar energy provides power to the loads as first priority. If solar energy is not sufficient to power all connected loads, battery energy will supply power to the loads at the same time. Utility provides power to the loads only when battery voltage drops to either low-level warning voltage or the setting point in program 12.
02	Maximum charging current:To configure total charging current for solar and utility chargers. (Max.charging current=utitliy charging current +solar charging current)	10A 02 * 10A	20A 02 * 20A
		30A 02 * 30A	40A 02 * 40A
		50A 02 * 50A	60A 02 * (default) 60A
		70A 02 * 70A	80A 02 * 80A

Program	Description	Selectable option	
03	AC input voltage range	Appliances (default) 03 * RPL	If selected, acceptable AC input voltage range will be within 90-280VAC
		UPS 03 * UPS	If selected, acceptable AC input voltage range will be within 170-280VAC
05	Battery type	AGM (default) 05 * AGM	Flooded 05 * FLD
		User -Defined 05 * USE	If "User-Defined" is selected, battery charge voltage and low DC cut-off voltage can be set up in program 26, 27 and 29
06	Auto restart when overload occurs	Restart disable (default) 06 * LFD	Restart enable 06 * LFE
07	Auto restart when over temperature occurs	Restart disable (default) 07 * LFD	Restart enable 07 * LFE
09	Output frequency	50Hz (default) 09 * 50	60Hz 09 * 60
10	Output voltage	220V 10 * 220	230V (default) 10 * 230
		240V 10 * 240	

Program	Description	Selectable option	
11	Maximum utility charging current Note: If setting value in program 02 is smaller than that in program in 11, the inverter will apply charging current from program 02 for utility charger.	2A 11 * 2	10A 11 * 10
		20A 11 * 20	30A (default) 11 * 30
		40A 11 * 40	50A 11 * 50
		60A 11 * 60	
12	Setting voltage point back to utility source when selecting "SBU priority" or "solar first" in program 01.	22.0V 12 * 22.0 <sub>BATT</sub> V	22.5V 12 * 22.5 <sub>BATT</sub> V
		23.0V (default) 12 * 23.0 <sub>BATT</sub> V	23.5V 12 * 23.5 <sub>BATT</sub> V
		24.0V 12 * 24.0 <sub>BATT</sub> V	24.5V 12 * 24.5 <sub>BATT</sub> V
		25.0V 12 * 25.0 <sub>BATT</sub> V	25.5V 12 * 25.5 <sub>BATT</sub> V



Program	Description	Selectable option	
13	Setting voltage point back to battery mode when selecting "SBU" (SBU priority) or "SUB" (solar first) in program 01.	Battery fully charged 13 FUL	24V 13 24.0 <sub>v</sub>
		24.5V 13 24.5 <sub>v</sub>	25V 13 25.0 <sub>v</sub>
		25.5V 13 25.5 <sub>v</sub>	26V 13 26.0 <sub>v</sub>
		26.5V 13 26.5 <sub>v</sub>	27V (default) 13 27.0 <sub>v</sub>
		27.5V 13 27.5 <sub>v</sub>	28V 13 28.0 <sub>v</sub>
		28.5V 13 28.5 <sub>v</sub>	29V 13 29.0 <sub>v</sub>
16	Charger source priority: To configure charger source priority	If this inverter/charger is working in Line, Standby or Fault mode, charger source can be programmed as below:	
		Solar first 16 CS0	Solar energy will charge battery as first priority. Utility will charge battery only when solar energy is not available.
		Solar and Utility (default) 16 SNU	Solar energy and utility will charge battery at the same time.
		Only Solar 16 OSO	Solar energy will be the only charger source no matter utility is available or not.
		If this inverter/charger is working in Battery mode or Power saving mode, only solar energy can charge battery. Solar energy will charge battery if it's available and sufficient.	

Program	Description	Selectable option	
18	Alarm control	Alarm on (default) 18 b0N	Alarm off 18 b0F
19	Auto return to default display screen	Return to default display screen (default) 19 ESP	If selected, no matter how users switch display screen, it will automatically return to default display screen (Input voltage /output voltage) after no button is pressed for 1 minute.
		Stay at latest screen 19 FEP	If selected, the display screen will stay at latest screen user finally switches.
20	Backlight control	Backlight on (default) 20 LON	Backlight off 20 LOF
22	Beeps while primary source is interrupted	Alarm on (default) 22 R0N	Alarm off 22 R0F
23	Overload bypass: When enabled, the unit will transfer to line mode if overload occurs in battery mode.	Bypass disable (default) 23 byd	Bypass enable 22 byE
25	Record Fault code	Record enable (default) 25 FEN	Record disable 25 FdS
26	Bulk charging voltage (C.V voltage)	26 CU 28.2 <sub>v</sub>	
		If self-defined is selected in program 5, this program can be set up. Setting range is from 25.0V to 31.5V for 3KW model. Increment of each click is 0.1V.	

Program	Description	Selectable option	
27	Floating charging voltage	<div> <div>27</div> <div>FLV</div> <div>BATT 27.0V</div> </div>	
		If self-defined is selected in program 5, this program can be set up. Setting range is from 25.0V to 31.5V for 3KW model . Increment of each click is 0.1V.	
29	Low DC cut-off voltage	<div> <div>29</div> <div>LOV</div> <div>BATT 21.0V</div> </div>	
		If self-defined is selected in program 5, this program can be set up. Setting range is from 21.0V to 24.0V for 3KW model . Increment of each click is 0.1V. Low DC cut-off voltage will be fixed to setting value no matter what percentage of load is connected.	
30	Battery equalization	Battery equalization <div>30</div> <div>EEN</div>	Battery equalization disable (default) <div>30</div> <div>EdS</div>
		If "Flooded" or "User-Defined" is selected in program 05, this program can be set up.	
31	Battery equalization voltage	<div> <div>31</div> <div>EV</div> <div>BATT 29.2V</div> </div>	
		Setting range is from 25.0V to 31.5V for 3KW model . Increment of each click is 0.1V.	



Program	Description	Selectable option	
33	Battery equalized time	60min (default) <div>33</div> <div>60</div>	Setting range is from 5min to 900min. Increment of each click is 5min.
34	Battery equalized timeout	120min (default) <div>34</div> <div>120</div>	Setting range is from 5min to 900min. Increment of each click is 5min.
35	Equalization interval	30days (default) <div>35</div> <div>30d</div>	Setting range is from 0 to 90 days. Increment of each click is 1 day
36	Equalization activated immediately	Enable <div>36</div> <div>REN</div>	Disable (default) <div>36</div> <div>RdS</div>
		If equalization function is enabled in program 30, this program can be set up. If "Enable" is selected in this program, it's to activate battery equalization immediately and LCD main page will shows " EQ ". If "Disable" is selected, it will cancel equalization function until next activated equalization time arrives based on program 35 setting. At this time, " EQ " will not be shown in LCD main page.	
37	Reset PV and Load energy storage	Not reset(Default) <div>37</div> <div>PrE</div>	Reset <div>37</div> <div>rSE</div>
93	Erase all data log	Not reset(Default) <div>93</div> <div>PrE</div>	Reset <div>93</div> <div>rSE</div>





Program	Description	Selectable option	
94	Data log stored period	3 days 94 ●	5 days 94 ●
		3	5
		10 days(Default) 94 ●	20 days 94 ●
		10	20
		30 days 94 ●	60 days 94 ●
		30	60
95	Time setting – Minute	For minute setting, the range is from 00 to 59 95 ● n1 n 00	
96	Time setting – Hour	For hour setting, the range is from 00 to 23 96 ● HOu 00	
97	Time setting– Day	For day setting, the range is from 00 to 31 97 ● dAY 01	
98	Time setting– Month	For month setting, the range is from 01 to 12 98 ● n0n 01	
99	Time setting – Year	For year setting, the range is from 16 to 99 99 ● yEA 16	

## Function Setting















There are three function keys on the display panel to implement special functions such as USB OTG, timer setting for output source priority and timer setting for charger source priority.

### 1. USB Function Setting











Please insert USB disk into USB port (  ). Press and hold "  " button for 3 seconds to enter USB function setting mode. These functions include to upgrade inverter firmware, export data log and re-write internal parameters from USB disk.

Procedure	LCD Screen
<b>Step 1:</b> Press and hold "  " button for 3 seconds to enter USB function setting mode.	UPG ● ● SEt LOG
<b>Step 2:</b> Press "  ", "  " or "  " button to enter the selectable setting programs.	

**Step 3:** Please select setting program by following each procedure.

Program#	Operation Procedure	LCD Screen
 Upgrade firmware	If pressing "  " button to proceed the firmware upgrade function. If the selected function is ready, LCD will display "  ". Please press "  " button to confirm the selection again.	UPG ● ● t dY
	Press "  " to select "Yes" or "  " button to select "No". Then, press "  " button to exit setting mode.	UPG ● ● YES NO
 Re-write internal parameters	If pressing "  " button to proceed parameters re-write from USB function. If selected function is ready, LCD will display "  ". Please press "  " button to confirm the selection again.	SEt ● ● t dY
	Press "  " to select "Yes" or "  " button to select "No". Then, press "  " button to exit setting mode.	SEt ● ● YES NO



Program#	Operation Procedure	LCD Screen
 Export data log	If pressing "  " button to export data log from USB disk to the inverter. If selected function is ready, LCD will display "  ". Please press "  " button to confirm the selection again.	 LOG  LOG 1-24
	Press "  " to select "Yes" or "  " button to select "No". Then, press "  " button to exit setting mode.	 LOG YES NO
	<b>IMPORTANT NOTE:</b> After this function is executed, partial LCD setting programs will be locked. For the detailed information, please check your installer directly.	

If no button is pressed for 1 minute, it will automatically return to main screen.






#### Error message for USB On-the-Go functions:

Error Code	Messages
U01	No USB disk is detected.
U02	USB disk is protected from copy.
U03	Document inside the USB disk with wrong format.












If any error occurs, error code will only show 3 seconds. After three seconds, it will automatically return to display screen.























## 2. Timer Setting for Output Source Priority

This timer setting is to set up the output source priority per day.

Procedure	LCD Screen
<b>Step 1:</b> Press and hold "  " button for 3 seconds to enter timer setting mode for output source priority.	 USB SUB SBU
<b>Step 2:</b> Press "  ", "  " or "  " button to enter the selectable setting programs.	

**Step 3:** Please select setting program by following each procedure.






Program#	Operation Procedure	LCD Screen
	If pressing "  " button to set up timer. Press "  " to select start time. Press "  " or "  " button to set the start time and then press "  " button to confirm. Press "  " button to select end time. Press "  " or "  " button to set the end time and then press "  " button to confirm. The setting range is from 00 to 23. Increment of each click is 1 hour.	 USB 00 23

Program#	Operation Procedure	LCD Screen
	If pressing "  " button to set up timer. Press "  " to select start time. Press "  " or "  " button to set the start time and then press "  " button to confirm. Press "  " button to select end time. Press "  " or "  " button to set the end time and then press "  " button to confirm. The setting range is from 00 to 23. Increment of each click is 1 hour.	 SUB 00 23
	If pressing "  " button to set up timer. Press "  " to select start time. Press "  " or "  " button to set the start time and then press "  " button to confirm. Press "  " button to select end time. Press "  " or "  " button to set the end time and then press "  " button to confirm. The setting range is from 00 to 23. Increment of each click is 1 hour.	 SBU 00 23























Press " " button to exit setting mode.

## 3. Timer Setting for the Charger Source Priority

This timer setting is to set up the charger source priority per day.

Procedure	LCD Screen
<b>Step 1:</b> Press and hold "  " button for 3 seconds to enter timer setting mode for charger source priority.	 CSO SNU OSO
<b>Step 2:</b> Press "  ", "  " or "  " button to enter the selectable setting programs.	

**Step 3:** Please select setting program by following each procedure.




Program#	Operation Procedure	LCD Screen
	If pressing "  " button to set up timer. Press "  " to select start time. Press "  " or "  " button to set the start time and then press "  " button to confirm. Press "  " button to select end time. Press "  " or "  " button to set the end time and then press "  " button to confirm. The setting range is from 00 to 23. Increment of each click is 1 hour.	 CSO 00 23
	If pressing "  " button to set up timer. Press "  " to select start time. Press "  " or "  " button to set the start time and then press "  " button to confirm. Press "  " button to select end time. Press "  " or "  " button to set the end time and then press "  " button to confirm. The setting range is from 00 to 23. Increment of each click is 1 hour.	 SNU 00 23






Program#	Operation Procedure	LCD Screen
300	If pressing "300" button to set up timer. Press "300" to select start time. Press "▲" or "▼" button to set the start time and then press "↵" button to confirm. Press "300" button to select end time. Press "▲" or "▼" button to set the end time and then press "↵" button to confirm. The setting range is from 00 to 23. Increment of each click is 1 hour.	050 00 23






Press "300" button to exit setting mode.






## Display Setting

The LCD display information will be switched in turns by pressing "UP" or "DOWN" key. The selectable information is switched as the following table in order.





Selectable information	LCD display
Input voltage/Output voltage (Default Display Screen)	Input Voltage=230V, output voltage=230V 
Input frequency	Input frequency=50Hz 
PV voltage	PV voltage=260V 






Selectable information	LCD display
PV current	PV current = 2.5A 
PV power	PV power = 500W 
Charging current	AC and PV charging current=50A 
	PV charging current=50A 
	AC charging current=50A 



Selectable information	LCD display
Charging power	<p>AC and PV charging power=500W</p> 
	<p>PV charging power=500W</p> 
	<p>AC charging power=500W</p> 
Battery voltage and output voltage	<p>Battery voltage=25.5V,output voltage=230V</p> 
Output frequency	<p>Output frequency=50Hz</p> 

Selectable information	LCD display
Load percentage	<p>Load percent:70%</p> 
Load in VA	<p>When connected load is lower than 1kVA, load in VA will present xxxVA like below chart.</p>  <p>When load is larger than 1kVA (<math>\geq 1\text{kVA}</math>), load in VA will present x.xxKVA like below chart.</p> 
Load in Watt	<p>When load is lower than 1KW,load in W will present xxxW like below chart.</p>  <p>When load is larger than 1KW (<math>\geq 1\text{KW}</math>), load in W will present x.xxKW like below chart.</p> 














Selectable information	LCD display
Battery voltage/Inverter temperature and solar charger controller temperature inside (Inverter temperature and SCC temperature is displayed in turns)	<p>Battery voltage=25.5V, Inverter temperature=50°C</p>  <p>Battery voltage=25.5V, SCC temperature=40°C</p> 
PV energy generated today and Load output energy today	<p>This PV Today energy=3.88kWh, Load Today energy=9.88kWh.</p> 
PV energy generated this month and Load output energy this month	<p>This PV month energy=388kWh, Load Today energy=988kWh.</p> 







Selectable information	LCD display
PV energy generated this year and Load output energy this year.	<p>This PV year energy=3.88MWh, Load year energy=9.88MWh.</p> 
PV energy generated totally and Load output total energy.	<p>PV Total energy=38.8MWh, Load Output Total energy=98.8MWh.</p> 
Real date	<p>Real date Nov 28, 2017.</p> 
Real time	<p>Real time 13:20</p> 
Main CPU version checking	<p>Main CPU version 00020.43.</p> 

Selectable information	LCD display
Secondary CPU version checking	Secondary CPU version 00001.08. 
Wifi version checking	Wifi version 00002.00. 

#### Operating Mode Description

Operation mode	Description	LCD display
Standby mode / Power saving mode  <b>Note:</b>  *Standby mode: The inverter is not turned on yet but at this time, the inverter can charge battery without AC output.  *Power saving mode: If enabled, the output of inverter will be off when connected load is pretty low or not detected.	No output is supplied by the unit but it still can charge batteries	Charging by utility and PV energy 
		Charging by utility 
		Charging by PV energy. 
		No charging 

Operation mode	Description	LCD display
Fault mode  <b>Note:</b>  *Fault mode: Errors are caused by inside circuit error or external reasons such as over temperature, output short circuited and so on.	PV energy and utility can charge batteries.	Charging by utility and PV energy 
		Charging by utility 
		Charging by PV energy. 
		No charging 
Line Mode	The unit will provide output power from the mains. It will also charge the battery at line mode.	Charging by utility and PV energy 
	The unit will provide output power from the mains. It will also charge the battery at line mode.  If "SUB" (solar first) is selected as output source priority and solar energy is not sufficient to provide the load, solar energy and the utility will provide the loads and charge the battery at the same time.	Charging by utility 
		

Operation mode	Description	LCD display
Line Mode	The unit will provide output power from the mains. It will also charge the battery at line mode.	<p>If "SUB" (solar first) is selected as output source priority and battery is not connected, solar energy and the utility will provide the loads.</p> 
		<p>Power from utility</p> 
Batter Mode	The unit will provide output power from battery and/or PV power	<p>Power from battery and PV energy.</p> 
		<p>PV energy will supply power to the loads and charge battery at the same time. No utility is available.</p> 
		<p>Power from battery only.</p> 
	The unit will provide output power from battery and PV power	<p>Power from PV energy only.</p> 

## Battery Equalization Description

Equalization function is added into charge controller. It reverses the buildup of negative chemical effects like stratification, a condition where acid concentration is greater at the bottom of the battery than at the top.

Equalization also helps to remove sulfate crystals that might have built up on the plates. If left unchecked, this condition, called sulfation, will reduce the overall capacity of the battery. Therefore, it's recommended to equalize battery periodically.


### • How to Apply Equalization Function

You must enable battery equalization function in monitoring LCD setting program 30 first. Then, you may apply this function in device by either one of following methods:

1. Setting equalization interval in program 35.
2. Active equalization immediately in program 36.


### • When to Equalize

In float stage, when the setting equalization interval (battery equalization cycle) is arrived, or equalization is active immediately, the controller will start to enter Equalize stage.




### • Equalize charging time and timeout

In Equalize stage, the controller will supply power to charge battery as much as possible until battery voltage raises to battery equalization voltage. Then, constant-voltage regulation is applied to maintain battery voltage at the battery equalization voltage. The battery will remain in the Equalize stage until setting battery equalized time is arrived.





However, in Equalize stage, when battery equalized time is expired and battery voltage doesn't rise to battery equalization voltage point, the charge controller will extend the battery equalized time until battery voltage achieves battery equalization voltage. If battery voltage is still lower than battery equalization voltage when battery equalized timeout setting is over, the charge controller will stop equalization and return to float stage.



## Fault Reference Code

Fault Code	Fault Event	Icon on
01	Fan is locked when inverter is off	F01
02	Over temperature	F02
03	Battery voltage is too high	F03
04	Battery voltage is too low	F04
05	Output short circuited or over temperature is detected by internal converter components	F05
06	Output voltage is too high	F06
07	Overload time out	F07
08	Bus voltage is too high	F08
09	Bus soft start failed	F09
51	Over current or surge	F51
52	Bus voltage is too low	F52
53	Inverter soft start failed	F53
55	Over DC voltage in AC output	F55
57	Current sensor failed	F57
58	Output voltage is too low	F58
59	PV voltage is over limitation	F59

## Warning Indicator

Warning Code	Warning Event	Audible Alarm	Icon flashing
01	Fan is locked when inverter is on	Beep three times every second	01
02	Over temperature	None	02
03	Battery is over-charged	Beep once every second	03
04	Low battery	Beep once every second	04
07	Overload	Beep once every 0.5 second	07
10	Output power derating	Beep twice every 3 seconds	10
15	PV energy is low	Beep twice every 3 seconds	15
16	High AC input (>280VAC) during BUS soft start	None	16
32	Communication interrupted	None	32
E9	Battery equalization	None	E9
bP	Battery is not connected	None	bP

## SPECIFICATIONS

Table 1 Line Mode Specifications



INVERTER MODEL	3KW
Input Voltage Waveform	Sinusoidal (utility or generator)
Nominal Input Voltage	230Vac
Low Loss Voltage	170Vac±7V (UPS); 90Vac±7V (Appliances)
Low Loss Return Voltage	180Vac±7V (UPS); 100Vac±7V (Appliances)
High Loss Voltage	280Vac±7V
High Loss Return Voltage	270Vac±7V
Max AC Input Voltage	300Vac
Nominal Input Frequency	50Hz / 60Hz (Auto detection)
Low Loss Frequency	40±1Hz
Low Loss Return Frequency	42±1Hz
High Loss Frequency	65±1Hz
High Loss Return Frequency	63±1Hz
Output Short Circuit Protection	Circuit Breaker
Efficiency (Line Mode)	>95% ( Rated R load, battery full charged )
Transfer Time	10ms typical (UPS); 20ms typical (Appliances)
Output power derating: When AC input voltage drops to 170V, the output power will be derated	<p>Sinusoidal (utility or generator)</p> 

Table 2 Inverter Mode Specifications

INVERTER MODEL	3KW
Rated Output Power	3KVA/3KW
Output Voltage Waveform	Pure Sine Wave
Output Voltage Regulation	230Vac±5%
Output Frequency	50Hz
Peak Efficiency	93%
Overload Protection	5s@≥130% load; 10s@105%~130% load
Surge Capacity	2* rated power for 5 seconds
Nominal DC Input Voltage	24Vdc
Cold Start Voltage	23.0Vdc
Low DC Warning Voltage @ load < 50% @ load ≥ 50%	23.0Vdc 22.0Vdc
Low DC Warning Return Voltage @ load < 50% @ load ≥ 50%	23.5Vdc 23.0Vdc
Low DC Cut-off Voltage @ load < 50% @ load ≥ 50%	21.5Vdc 21.0Vdc
High DC Recovery Voltage	32Vdc
High DC Cut-off Voltage	33Vdc
No Load Power Consumption	<35W

Table 3 Charge Mode Specifications

Utility Charging Mode		
INVERTER MODEL	3KW	
Charging Algorithm	3-Step	
AC Charging Current (Max)	60Amp (@VI/P=230Vac)	
Bulk Charging Voltage	Flooded Battery	29.2
	AGM / Gel Battery	28.2
Floating Charging Voltage	27Vdc	
Charging Curve		

MPPT Solar Charging Mode	
<b>INVERTER MODEL</b>	<b>3KW</b>
Max. PV Array Power	4000W
Nominal PV Voltage	240Vdc
PV Array MPPT Voltage Range	120~450Vdc
Max. PV Array Open Circuit Voltage	500Vdc
Max Charging Current (AC charger plus solar charger)	80Amp

**Table 4 General Specifications**

<b>INVERTER MODEL</b>	<b>3KW</b>
Operating Temperature Range	-10°C to 50°C
Storage temperature	-15°C~ 60°C
Humidity	5% to 95% Relative Humidity (Non-condensing)
Dimension (D*W*H), mm	130 x 300 x 492
Net Weight, kg	9.3

## TROUBLE SHOOTING

Problem	LCD/LED/Buzzer	Explanation / Possible cause	What to do
Unit shuts down automatically during startup process	LCD/LEDs and buzzer will be active for 3 seconds and then complete off	The battery voltage is too low (<1.91V/Cell)	1. Re-charge battery. 2. Replace battery.
No response after power on.	No indication.	1. The battery voltage is far too low. (<1.4V/Cell) 2. Internal fuse tripped.	1. Contact repair center for replacing the fuse. 2. Re-charge battery. 3. Replace battery
Mains exist but the unit works in battery mode.	Input voltage is displayed as 0 on the LCD and green LED is flashing.	Input protector is tripped	Check if AC breaker is tripped and AC wiring is connected well.
	Green LED is flashing.	Insufficient quality of AC power. (Shore or Generator)	1. Check if AC wires are too thin and/or too long. 2. Check if generator (if applied) is working well or if input voltage range setting is correct. (UPS→Appliance)
	Green LED is flashing.	Set "SUB" (solar first) as the priority of output source.	Change output source priority to "USB" (utility first).

Problem	LCD/LED/Buzzer	Explanation / Possible cause	What to do
When the unit is turned on, internal relay is switched on and off repeatedly.	LCD display and LEDs are flashing	Battery is disconnected.	Check if battery wires are connected well.
Buzzer beeps continuously and red LED is on.	Fault code 07	Overload error. The inverter is overload 110% and time is up.	Reduce the connected load by switching off some equipment.
		If PV input voltage is higher than specification, the output power will be derated. At this time, if connected loads is higher than derated output power, it will cause overload.	Reduce the number of PV modules in series or the connected load.
	Fault code 05	Output short circuited.	Check if wiring is connected well and remove abnormal load.
		Temperature of internal converter component is over 120°C.	Check whether the air flow of the unit is blocked or whether the ambient temperature is too high.
	Fault code 02	Internal temperature of inverter component is over 100°C.	
	Fault code 03	Battery is over-charged.	Return to repair center.
		The battery voltage is too high.	Check if spec and quantity of batteries are meet requirements.
	Fault code 01	Fan fault	Replace the fan.
	Fault code 06/58	Output abnormal (Inverter voltage below than 190Vac or is higher than 260Vac)	1. Reduce the connected load. 2. Return to repair center
	Fault code 08/09/53/57	Internal components failed.	Return to repair center.
	Fault code 51	Over current or surge.	Restart the unit, if the error happens again, please return to repair center.
	Fault code 52	Bus voltage is too low.	
	Fault code 55	Output voltage is unbalanced.	Reduce the number of PV modules in series.
	Fault code 59	PV input voltage is beyond the specification.	

## Appendix: Approximate Back-up Time Table

Model	Load (VA)	Backup Time @ 24Vdc 100Ah (min)	Backup Time @ 24Vdc 200Ah (min)
3KW	300	449	1100
	600	222	525
	900	124	303
	1200	95	227
	1500	68	164
	1800	56	126
	2100	48	108
	2400	35	94
	2700	31	74
	3000	28	67
	3200	25	61