


User Manual

5KVA-48V INVERTER / CHARGER



<ftp-smartree.y66.dnsnd.com/WIFImonitor.apk>

Version: 1.0

Table of Contents

| | |
|---|-----------|
| ABOUT THIS MANUAL | 1 |
| Purpose..... | 1 |
| Scope | 1 |
| SAFETY INSTRUCTIONS..... | 1 |
| INTRODUCTION | 2 |
| Features | 2 |
| Basic System Architecture | 2 |
| Product Overview..... | 3 |
| INSTALLATION | 4 |
| Unpacking and Inspection..... | 4 |
| Preparation | 4 |
| Mounting the Unit..... | 4 |
| Battery Connection | 5 |
| AC Input/Output Connection | 7 |
| PV Connection | 9 |
| Final Assembly..... | 10 |
| Communication Connection..... | 10 |
| Dry Contact Signal | 10 |
| OPERATION | 11 |
| Power ON/OFF | 11 |
| Operation and Display Panel | 11 |
| LCD Display Icons | 12 |
| LCD Setting..... | 14 |
| Display Setting | 21 |
| Operating Mode Description | 24 |
| Fault Reference Code..... | 25 |
| Warning Indicator | 26 |
| SPECIFICATIONS | 27 |
| Table 1: Line Mode Specifications | 27 |
| Table 2: Inverter Mode Specifications..... | 28 |
| Table 3: Charging Mode Specifications | 28 |
| Table 4 General Specifications | 29 |
| TROUBLESHOOTING | 30 |
| Appendix I: Approximate Back-up Time Table | 31 |
| Appendix II: Parallel function | 32 |

ABOUT THIS MANUAL

Purpose

This manual describes the assembly, installation, operation and troubleshooting of this unit. Please read this manual carefully before installations and operations. Keep this manual for future reference.

Scope

This manual provides safety and installation guidelines as well as information on tools and wiring.

SAFETY INSTRUCTIONS



WARNING: This chapter contains important safety and operating instructions. Read and keep this manual for future reference.

1. Before using the unit, read all instructions and warnings marked on the unit, the batteries and all appropriate sections of this manual.
2. **CAUTION** --To reduce risk of injury, charge it with only deep-cycle lead acid type rechargeable batteries. It might cause burst or result in physical injury and damage if you charge it with other types of the batteries.
3. Do not disassemble the unit at will. For servicing or repairs, it' s advised to take it to an authorized service center. Incorrect re-assembly may result in a risk of electric shock or fire.
4. To reduce the risk of electric shock, unplug all wirings from the wall outlet before any maintenance or cleaning. Turning off the unit will not reduce this risk.
5. **CAUTION** – Only qualified personnel can install this device with battery.
6. **NEVER** charge a frozen battery.
7. For optimum operation of this inverter/charger, please follow required spec to select appropriate cable size. It' s very important to correctly operate this inverter/charger.
8. Be very cautious when working with metal tools on or around the batteries. A potential risk exists when you drop tools on or around the batteries. Spark, short circuited batteries or other electrical parts might cause an explosion.
9. Please strictly follow installation procedure when you want to disconnect AC or DC terminals. Please refer to the INSTALLATION section of this manual for the details.
10. Fuses are provided for over-current protection of the battery supply.
11. GROUNDING INSTRUCTIONS -This inverter/charger should be connected to a permanent grounded wiring system. Be sure to comply with local requirements and regulation to install this inverter.
12. NEVER cause AC output and DC input short circuited. Do NOT connect to the mains when DC input short circuits.
13. **Warning!!** Only qualified service staffs are able to operate this device. If errors still persist after following the troubleshooting table, please send this inverter/charger back to the local dealer or service center for maintenance.

INTRODUCTION

This is a multi-functional inverter/charger, combining the functions of inverter, MPPT solar charger and battery charger to offer uninterruptible power support with portability. Its comprehensive LCD display offers user-configurable and easy-accessible button operation such as battery charging current, priority setting for AC/solar charger, and acceptable input voltage setting to suit different applications.

Features

- Pure sine wave inverter
- Built-in MPPT solar charge controller
- Configurable input voltage range for home appliances and personal computers via LCD setting
- Configurable battery charging current to suit different applications via LCD setting
- Configurable priority of AC/Solar Charger via LCD setting
- Compatible to mains voltage or generator power
- Automatic restart while AC is recovering
- Overload/ Over temperature/ short circuit protection
- Smart battery charger design to optimize battery performance
- Cold start function

Basic System Architecture

The following illustration shows basic application of this inverter/charger. It also includes the following devices to complete the whole running system:

Generator or Utility.

PV modules

Consult your system integrator for other possible system architectures depending on your requirements.

This inverter can power all kinds of appliances at home or in the office, including motor-type appliances such as tube light, fan, refrigerator and air conditioner.





Figure 1 Hybrid Power System

Product Overview




1. Battery connector
2. Power on/off switch
3. Dry contact
4. USB communication port
5. RS232 communication port
6. PV input
7. Parallel communication port
8. Current sharing port
9. Parallel ID (Please check chapter 6 in Parallel Function for setting details.)
10. AC output
11. Circuit breaker
12. AC input
13. LCD display
14. Status indicator
15. Charging indicator
16. Fault indicator
17. Function buttons

INSTALLATION

Unpacking and Inspection

Before installation, please inspect the unit. Be sure that nothing inside the package is damaged. You should have received the following items inside the package:



The unit



Mounting plate



Fixing screws



USB cable



Parallel communication cable




User manual



Current sharing cable

Preparation

Before connecting all wirings, please take off the cover of the bottom by removing the six screws as shown below.



Mounting the Unit

Consider the following points before selecting where to install:

- Do not mount the inverter on any flammable construction materials.


- Mount this inverter on a solid surface

- Install this inverter at eye level in order to read the LCD display at all times.

- The ambient temperature should be between 0°C and 55°C to ensure optimal operation.

- The inverter should be adhered to the wall vertically.

- Be sure to keep other objects away and leave the space in a minimum as shown in the right diagram to guarantee sufficient heat dissipation and enough space for replacing wires.





SUITABLE FOR MOUNTING ON CONCRETE OR OTHER NON-COMBUSTIBLE SURFACE ONLY.

Install the unit by screwing four screws as shown in the diagram.

It's recommended to use M5 screws.

1. Drill four holes in the marked locations with 4 screws. The reference tightening torque is 35 N.m.
2. Raise the inverter and place it over the mounting plate.




Battery Connection

CAUTION: For safety operation and regulation compliance, it's requested to install a separate DC over-current protector or disconnect the device between battery and inverter. It may not be necessary to disconnect the device for some applications, however, it's requested to have over-current protection installed. Please refer to the typical amperage in the table below as required fuse or size of the breaker.

WARNING! All wiring must be performed by a qualified personnel.

WARNING! It's very important for system safety and efficient operation to use appropriate cable for battery connection. To reduce risk of injury, please use proper cables and suitable size of terminal recommended below.

Ring terminal:




Recommended battery cables and size of terminal:


| Model | Typical Amperage | Battery Capacity | Wire Size | Ring Terminal | | | Torque Value |
|-------|------------------|------------------|-----------|-----------------------|------------|--------|--------------|
| | | | | Cable mm ² | Dimensions | | |
| | | | | | D (mm) | L (mm) | |
| 5KW | 220A | 200AH | 1*1/0AWG | 60 | 8.4 | 49.7 | 5~6 Nm |
| | | | 2*4AWG | 44 | 8.4 | 49.7 | |

Please follow the steps below to implement the battery connection:

1. Assemble battery ring terminal based on recommended battery cable and terminal size.
2. Connect all battery packs as units requires. It's suggested to connect at least 200Ah capacity battery for 5KW model.
3. Insert the ring terminal of battery cable flatly into battery connector of inverter and make sure the bolts are tightened with torque of 5-6 Nm. Make sure polarity at both the battery and the inverter is correctly connected and ring terminals are tightly screwed to the battery terminals.



4. Connect all battery packs as below chart.



WARNING: Shock Hazard

Installation must be performed with care due to high battery voltage in series.



CAUTION!! Do not place anything between the flat part of the inverter terminal and the ring terminal. Otherwise, overheating may occur.

CAUTION!! Do not apply any anti-oxidant substance on the terminals before the terminals are connected tightly.

CAUTION!! Before making the final DC connection or closing DC breaker/disconnector, be sure positive (+) must be connected to positive (+) and negative (-) must be connected to negative (-).

AC Input/Output Connection

CAUTION!! Before connecting to AC input power source, please install a **separate** AC breaker between inverter and AC input power source. This will ensure the inverter can be securely disconnected during maintenance and fully protected from over current of AC input. The recommended spec of AC breaker is 40A for 5KVA.

CAUTION!! There are two terminal blocks with "IN" and "OUT" markings. Please do NOT mis - connect input and output connectors.

WARNING! All wiring must be performed by the qualified personnel.


WARNING! It's necessary to connect AC input N wire. Otherwise, the inverter will NOT be able to detect AC input.

WARNING! It's very important for system safety and efficient operation to use appropriate cable for AC input connection. To reduce risk of injury, please use the recommended cable size as below.

Suggested cable requirement for AC wires

| Model | Gauge | Torque Value |
|-------|--------|--------------|
| 5KVA | 10 AWG | 1.4~ 1.6Nm |

There are three applications for different AC input as shown in the figure below. For phase angle operation, please refer to LCD #28



Please follow below steps to implement AC input/output connection:


1. Before making AC input/output connection, be sure to open DC protector or disconnecter first.
2. Remove insulation sleeve 10mm from the six conductors. And short-circuit phase L and neutral conductor N 3 mm.
3. Insert AC input wires according to polarities indicated on terminal block and tighten the terminal screws. Be sure to connect PE protective conductor (⊕) first.

⊕ → **Ground (yellow-green)**

L1 → **LINE (black)**

L2 → **LINE (brown)**

N → **Neutral (blue)**



WARNING:

Be sure that AC power source is disconnected before attempting to hardwire it to the unit.


4. Then, insert AC output wires according to polarities indicated on terminal block and fasten the terminal screws. Be sure to connect PE protective conductor (⊕) first.

⊕ → **Ground (yellow-green)**

L1 → **LINE (black)**

L2 → **LINE (brown)**

N → **Neutral (blue)**



5. Make sure the wires are securely connected.

CAUTION: Important

Be sure to connect AC wires with correct polarity. If L and N wires are connected reversely, it may cause utility short-circuited when these inverters are worked in parallel operation.

CAUTION: Appliances such as air conditioner are required at least 2~3 minutes to restart because it's require to have enough time to balance refrigerant gas inside of circuits. If a power shortage occurs and recovers in a short time, it will cause damage to your connected appliances. To prevent this kind of damage, please check with the manufacturer of the air conditioner if it's equipped with-time-delay function before installation. Otherwise, this inverter/charger will cause overload fault and cut off the output to protect your appliance but sometimes it still causes internal damage to the air conditioner.

PV Connection

CAUTION: Before connecting to PV modules, please install **separately** a DC circuit breaker between inverter and PV modules.

WARNING! All wiring must be performed by a qualified personnel.

WARNING! It's very important for system safety and efficient operation to use appropriate cable for PV module connection. To reduce risk of injury, please use the recommended cable size as below.

NOTICE! When only one MPPT is used, please use MPPT1 first.

| Model | Typical Amperage | Cable Size | Torque |
|-------|------------------|------------|------------|
| 5KVA | 80A | 8 AWG | 1.4~1.6 Nm |

PV Module Selection:



When selecting proper PV modules, please be sure to consider the parameters below:

1. Open circuit Voltage (Voc) of PV modules can't thexceede maximum voltage of the PV array open circuit of the inverter.
2. Open circuit Voltage (Voc) of PV modules should be higher than the minimum voltage of the battery.

| Solar Charging Mode | |
|------------------------------------|-----------|
| Solar Charger Type | MPPT |
| Number of MPPT | 2 |
| Max. PV Array Open Circuit Voltage | 145Vdc |
| PV Array MPPT Voltage Range | 60~115Vdc |
| Min. battery voltage for PV charge | 34Vdc |


Please follow the steps below to implement PV module connection:

1. Remove insulation sleeve 10 mm from positive and negative conductors.
2. Check the correct polarity of connected cable from PV modules and PV input connectors. Then, connect positive pole (+) of connection cable to positive pole (+) of PV input connector. Connect negative pole (-) of connection cable to negative pole (-) of PV input connector.
3. Make sure the wires are securely connected.



Final Assembly

After connecting all wirings, please put the bottom cover back by fixing two screws as shown below.




Communication Connection

Please use supplied communication cable to connect to inverter and PC. Insert bundled CD into a computer and follow the on-screen instructions to install the monitoring software. For the detailed software operations, please check user manual of software inside the CD.


Dry Contact Signal

There is one dry contact (3A/120VAC) available on the rear panel. It could be used to deliver signal to external device when battery voltage reaches warning level.

| Unit Status | Condition | | | Dry contact port:  | |
|-------------|--|---|--|---|--------|
| | | | | NC & C | NO & C |
| Power Off | Unit is off and no output is powered. | | | Close | Open |
| Power On | Output is powered from Utility. | | | Close | Open |
| | Output is powered from Battery or Solar. | Program 01 set as Utility | Battery voltage < Low DC warning voltage | Open | Close |
| | | | Battery voltage > Setting value in Program 13 or battery charging reaches floating stage | Close | Open |
| | | Program 01 is set as SBU or Solar first | Battery voltage < Setting value in Program 12 | Open | Close |
| | | | Battery voltage > Setting value in Program 13 or the battery charging reaches the floating stage | Close | Open |

OPERATION


Power ON/OFF



Once the unit has been properly installed and the batteries are connected well, simply press On/Off switch (located on the bottom of the inverter) to turn on the unit.

Operation and Display Panel

The operation and display panel, as shown in the chart below, are on the front panel of the inverter. It includes three indicators, four function keys and an LCD display, indicating the operating status and input/output power information.




LED Indicator













| LED Indicator | | | Messages |
|---------------|-------|----------|---|
| ☀ AC / ☀ INV | Green | Solid On | Output is powered by utility in Line mode. |
| | | Flashing | Output is powered by battery or PV in battery mode. |
| ☀ CHG | Green | Solid On | Battery is fully charged. |
| | | Flashing | Battery is charging. |
| ⚠ FAULT | Red | Solid On | Fault occurs in the inverter. |
| | | Flashing | Warning occurs in the inverter. |

Function Keys

| Function Key | Description |
|--------------|--|
| ESC | To exit setting mode |
| UP | To go to previous selection |
| DOWN | To go to next selection |
| ENTER | To confirm the selection in setting mode or enter setting mode |

LCD Display Icons



| Icon | Function description | |
|---|--|--|
| Input Source Information | | |
|  | Indicates the AC input. | |
|  | Indicates the PV input | |
|  | Indicates the input 1 and output 1 data. | |
|  | Indicates the input 2 and output 2 data. | |
|  | Indicates input voltage, input frequency, PV voltage, battery voltage and charger current. | |
| Configuration Program and Fault Information | | |
|  | Indicates the setting programs. | |
|  | Indicates the warning and fault codes. Warning:  flashing with warning code. | |
|  | Fault:  lighting with fault code | |
| Output Information | | |
|  | Indicate output voltage, output frequency, load percent, load in VA, load in Watt and discharging current. | |
| Battery Information | | |
|  | Indicates battery level by 0-24%, 25-49%, 50-74% and 75-100% in battery mode and charging status in line mode. | |
| In AC mode, it will present battery charging status. | | |
| Status | Battery voltage | LCD Display |
| Constant Current mode / Constant Voltage mode | <2V/cell | 4 bars will flash in turns. |
| | 2 ~ 2.083V/cell | Bottom bar will be on and the other three bars will flash in turns. |
| | 2.083 ~ 2.167V/cell | Bottom two bars will be on and the other two bars will flash in turns. |
| | > 2.167 V/cell | Bottom three bars will be on and the top |

| | | | | |
|--|--|--------------------|---------|----------|
| | | bar will flash. | | |
| In floating mode, batteries are fully charged. | | 4 bars will be on. | | |
| In battery mode, it will present battery capacity. | | | | |
| Load Percentage | Battery Voltage | LCD Display | | |
| Load >50% | < 1.717V/cell | | | |
| | 1.717V/cell ~ 1.8V/cell | | | |
| | 1.8 ~ 1.883V/cell | | | |
| | > 1.883 V/cell | | | |
| 50%> Load > 20% | < 1.817V/cell | | | |
| | 1.817V/cell ~ 1.9V/cell | | | |
| | 1.9 ~ 1.983V/cell | | | |
| | > 1.983 | | | |
| Load < 20% | < 1.867V/cell | | | |
| | 1.867V/cell ~ 1.95V/cell | | | |
| | 1.95 ~ 2.033V/cell | | | |
| | > 2.033 | | | |
| Load Information | | | | |
| | Indicates overload. | | | |
| | Indicates the load level by 0-24%, 25-50%, 50-74% and 75-100%. | | | |
| | 0%~25% | 25%~50% | 50%~75% | 75%~100% |
| | | | | |
| Mode Operation Information | | | | |
| | Indicates unit connects to the mains. | | | |
| | Indicates unit connects to the PV panel. | | | |
| | Indicates load is supplied by utility power. | | | |
| | Indicates the utility charger circuit is working. | | | |
| | Indicates the DC/AC inverter circuit is working. | | | |
| | Indicates the PV charger circuit is working. | | | |
| Mute Operation | | | | |
| | Indicates the alarm is disabled. | | | |

LCD Setting

After pressing and holding the ENTER button for 3 seconds, the unit will enter setting mode. Press "UP" or "DOWN" buttons to select setting programs. And then, press "ENTER" button to confirm the selection or ESC button to exit.

Setting Programs:








| Program | Description | Selectable option | |
|---------|---|-----------------------------------|--|
| 00 | Exit setting mode | Escape 00 ESC | |
| 01 | Output source priority: To configure load power source priority | Solar first 01 SOL | Solar energy provides power to the loads as first priority. If solar energy is not sufficient to power all connected loads, battery energy will supply power to the loads at the same time. Utility provides power to the loads only when any one condition stated below happens: - Solar energy is not available - Battery voltage drops to either low DC warning voltage or the setting point in program 12. |
| | | Utility first (default) 01 UTI | Utility will provide power to the loads as first priority. Solar and battery energy will provide power to the loads only when utility power is not available. |
| | | SBU priority 01 SBU | Solar energy provides power to the loads as first priority. If solar energy is not sufficient to power all connected loads, battery energy will supply power to the loads at the same time. Utility provides power to the loads only when battery voltage drops to either low DC warning voltage or the setting point in program 12. |
| 02 | Maximum charging current: To configure the total charging current for solar and utility chargers. (Max. charging current = utility charging current + solar charging current) | 20A 02 20 A | 30A 02 30 A |

| | | | |
|----|---|-------------------------------------|--|
| 02 | Maximum charging current: To configure the total charging current for solar and utility chargers. (Max. charging current = utility charging current + solar charging current) | 40A 02 40 ^A | 50A 02 50 ^A |
| | | 60A (default) 02 60 ^A | 70A 02 70 ^A |
| | | 80A 02 80 ^A | 90A 02 90 ^A |
| | | 100A 02 100 ^A | 110A 02 110 ^A |
| | | 120A 02 120 ^A | 130A 02 130 ^A |
| | | 140A 02 140 ^A | 150A 02 150 ^A |
| | | 160A 02 160 ^A | 170A 02 170 ^A |
| | | 180A 02 180 ^A | 190A 02 190 ^A |
| | | 200A 02 200 ^A | 210A 02 210 ^A |
| | | 220A 02 220 ^A | |
| 03 | AC input voltage range | Appliances (default) 03 APL | If selected, acceptable AC input voltage range will be within 65-140VAC. |
| | | UPS 03 UPS | If selected, acceptable AC input voltage range will be within 95-140VAC. |
| 05 | Battery type | AGM (default) 05 AGM | Flooded 05 FLD |

| | | | |
|----|--|--|--|
| | | User-Defined 05 USE | If "User-Defined" is selected, battery charge voltage and low DC cut-off voltage can be set up in program 26, 27 and 29. |
| 06 | Automatically restart when overload occurs | Restart disable (default) 06 LFD | Restart enable 06 LFE |
| 07 | Automatically restart when over temperature occurs | Restart disable (default) 07 LFD | Restart enable 07 LFE |
| 08 | Output voltage | 110V 08 110 ^v | 120V (default) 08 120 ^v |
| 09 | Output frequency | 50Hz 09 50 ^{Hz} | 60Hz (default) 09 60 ^{Hz} |
| 11 | Maximum utility charging current | 10A 11 10A | 20A 11 20A |
| | | 30A (default) 11 30A | 40A 11 40A |
| | | 50A 11 50A | 60A 11 60A |
| 12 | Setting voltage point back to utility source when selecting "SBU priority" or "Solar first" in program | 44.0V 12 ^{BATT} 440 ^v | 45.0V (default) 12 ^{BATT} 450 ^v |
| | | 46.0V 12 ^{BATT} 460 ^v | 47.0V 12 ^{BATT} 470 ^v |
| | | 48.0V 12 ^{BATT} 480 ^v | 49.0V 12 ^{BATT} 490 ^v |
| | | 50.0V 12 ^{BATT} 500 ^v | 51.0V 12 ^{BATT} 510 ^v |

| | | | |
|----|---|---|--|
| 13 | Setting voltage point back to battery mode when selecting "SBU priority" or "Solar first" in program 01 | Battery fully charged 13 ^{BATT} FUL | 48.0V 13 ^{BATT} 480 ^v |
| | | 49.0V 13 ^{BATT} 490 ^v | 50.0V 13 ^{BATT} 500 ^v |
| | | 51.0V 13 ^{BATT} 510 ^v | 52.0V 13 ^{BATT} 520 ^v |
| | | 53.0V 13 ^{BATT} 530 ^v | 54.0V (default) 13 ^{BATT} 540 ^v |
| | | 55.0V 13 ^{BATT} 550 ^v | 56.0V 13 ^{BATT} 560 ^v |
| | | 57.0V 13 ^{BATT} 570 ^v | 58.0V 13 ^{BATT} 580 ^v |
| 16 | Charger source priority: To configure the priority of charger source | If this inverter/charger is working in Line, Standby or Fault mode, charger source can be programmed as below: | |
| | | Solar first 16 ^C 50 | Solar energy will charge battery as first priority. Utility will charge battery only when solar energy is not available. |
| | | Utility first 16 ^C UT | Utility will charge battery as first priority. Solar energy will charge battery only when utility power is not available. |
| | | Solar and Utility (default) 16 ^S NU | Solar energy and utility will charge battery at the same time. |
| | | Only Solar 16 ^C 050 | Solar energy will be the only charger source no matter utility is available or not. |
| 18 | Alarm control | If this inverter/charger is working in Battery mode, only solar energy can charge battery. Solar energy will charge battery if it's available and sufficient. | |
| | | Alarm on (default) 18 ^b ON | Alarm off 18 ^b OF |

| | | | |
|----|---|--|---|
| 19 | Automatically return to default display screen | Return to default display screen (default) 19 ESP | If selected, no matter how users switch display screen, it will automatically return to default display screen (Input voltage /output voltage) after no button is pressed for 1 minute. |
| | | Stay at latest screen 19 LEP | If selected, the display screen will stay at the latest screen user finally switches. |
| 20 | Backlight control | Backlight on (default) 20 LON | Backlight off 20 LOF |
| 22 | Beeps while primary source is interrupted | Alarm on (default) 22 AON | Alarm off 22 AOF |
| 23 | Overload bypass: When enabled, the unit will transfer to line mode if overload occurs in battery mode. | Bypass disable (default) 23 bYd | Bypass enable 23 bYE |
| 25 | Record Fault code | Record enable 25 FEN | Record disable (default) 25 FdS |
| 26 | Bulk charging voltage (C.V voltage) | Default setting: 56.4V CU 26 ^{BATT} 56.4 _v | |
| | | If self-defined is selected in program 5, this program can be set up. Setting range is from 48.0V to 58.4V. Increment of each click is 0.1V. | |
| 27 | Floating charging voltage | Default setting: 54.0V FLU 27 ^{BATT} 54.0 _v | |
| | | If self-defined is selected in program 5, this program can be set up. Setting range is from 48.0V to 58.4V. Increment of each click is 0.1V. | |
| 28 | AC output mode *This setting is able to set up only when the inverter is in standby mode. Be sure that on/off switch is in "OFF" status. | Parallel output in single phase. Output voltage is 120V. 28 ^{OUTPUT} 2A0 | Support L1 phase output on 3-Phase application. Output voltage is 120V. 28 ^{OUTPUT} 3P 1 |

| | | | |
|----|---|--|--|
| 28 | AC output mode *This setting is able to set up only when the inverter is in standby mode. Be sure that on/off switch is in "OFF" status. | Support L2 phase output on 3-Phase application. Output voltage is 120V. | Support L3 phase output on 3-Phase application. Output voltage is 120V. |
| | |  |  |
| | | Support L1/L2 phase output on split phase application with L1 to L2 output voltage in 208V. | Support L1/L2 phase output on split phase application with L1 to L2 output voltage in 240V. |
| | |  |  |
| 29 | Low DC cut-off voltage | Default setting: 42.0V  | |
| | | If self-defined is selected in program 5, this program can be set up. Setting range is from 40.0V to 48.0V. Increment of each click is 0.1V. Low DC cut-off voltage will be fixed to setting value no matter what percentage of load is connected. | |
| 30 | PV judge condition (Only apply for setting "Solar first" in program 1: Output source priority) | One Inverter (Default):  | When "ONE" is selected, as long as one of the inverters has been connected to PV modules and PV input is normal, parallel or 3-phase system will continue working according to rule of "solar first" setting. For example, two units are connected in parallel and set "SOL" in output source priority. If one of the two units has connected to PV modules and PV input is normal, the parallel system will provide power to loads from solar or battery power. If both of them are not sufficient, the system will provide power to loads from utility. |
| | | All of Inverters:  | When "ALL" is selected, parallel or 3-phase system will continue working according to rule of "solar first" setting only when all of inverters are connected to PV modules. For example, two units are connected in parallel and set "SOL" in output source priority. When "ALL" is selected in program 30, it's necessary to have all inverters connected to PV modules and PV input is normal to allow the system to provide power to loads from solar and battery power. Otherwise, the system will provide power to loads from utility. |






| | | | |
|---|---|--|--|
| 31 | Solar power balance: When enabled, solar input power will be automatically adjusted according to the connected load power. | Solar power balance enable (Default): 31 5bE | If selected, solar input power will be automatically adjusted according to the following formula: Max. input solar power = Max. battery charging power + Connected load power. |
| | | Solar power balance disable: 31 5bd | If selected, the solar input power will be the same as max. battery charging power no matter how many loads are connected. The max. battery charging power will be based on the setting current in program 02. (Max. solar power = Max. battery charging power) |
| 32 | Bulk charging time (C.V stage) | Automatically (Default): 32 AUT | If selected, inverter will judge this charging time automatically. |
| | | 5 min 32 5 | The setting range is from 5 min to 900 min. Increment of each click is 5 min. |
| | | 900 min 32 900 | |
| If "USE" is selected in program 05, this program can be set up. | | | |
| 33 | Battery equalization | Battery equalization 33 EEN | Battery equalization disable (default) 33 EdS |
| | | If "Flooded" or "User-Defined" is selected in program 05, this program can be set up. | |
| 34 | Battery equalization voltage | Default setting: 58.4V. Setting range is from 48V ~ 58.4V. Increment of each click is 0.1V. EV 34 58.4 ^{BATT} V | |
| 35 | Battery equalized time | 60min (default) 35 60 | Setting range is from 5min to 900min. Increment of each click is 5min. |
| 36 | Battery equalized timeout | 120min (default) 36 120 | Setting range is from 5min to 900 min. Increment of each click is 5 min. |
| 37 | Equalization interval | 30days (default) 37 30d | Setting range is from 0 to 90 days. Increment of each click is 1 day |
| 39 | Equalization activated immediately | Enable 39 AEN | Disable (default) 39 AdS |






| | | |
|--|--|--|
| | | <p>If equalization function is enabled in program 33, this program can be set up. If "Enable" is selected in this program, it's to activate battery equalization immediately and LCD main page will shows E9 . If "Disable" is selected, it will cancel equalization function until next activated equalization time arrives based on program 37 setting. At this time, E9 will not be shown in LCD main page.</p> |
|--|--|--|

Display Setting







The LCD display information will be switched in turns by pressing "UP" or "DOWN" key. The selectable information is switched as the following table order.

| Selectable information | LCD display |
|---|--|
| AC Input 1 voltage/ AC output 1 voltage (Default Display Screen) | <p>AC Input 1 Voltage=230V, AC output 1 voltage=230V</p> |
| AC Input 2 voltage/ AC output 2 voltage | <p>AC Input 2 Voltage=230V, AC output 2 voltage=230V</p> |
| AC Input 1 frequency/AC output 1 frequency | <p>AC Input 1 frequency=50Hz, AC output 1 frequency=50Hz</p> |
| AC Input 2 frequency /AC output 2 frequency | <p>AC Input 2 frequency=50Hz, AC output 2 frequency=50Hz</p> |

| | |
|--|--|
| <p>MPPT Input 1 Charging current / MPPT Input 1 Charging power</p> | <p>PV1 voltage=60V , PV1 Power = 200W</p>  |
| <p>MPPT Input 2 Charging current / MPPT Input 2 Charging power</p> | <p>PV2 voltage=60V ,PV2 Power = 200W</p>  |
| <p>Load 1 Watt/ Load 1 percentage</p> | <p>Load 1 Watt=200W, Load 1 percent=60%</p>  |
| <p>Load 2 Watt/ Load 2 percentage</p> | <p>Load 2 Watt=200W, Load 2 percent=60%</p>  |
| <p>Load 1 Watt/ Load 1 in VA</p> | <p>Load 1 Watt=200W, Load 1 in VA=600VA</p>  |

| | |
|---|--|
| Load 2 Watt/ Load 2 in VA | <p>Load 2 Watt 200W, Load 2 in VA=600VA</p>  <p>The LCD display shows '500 W' and '600 VA'. Below the display is a schematic diagram showing a solar panel connected to an MPPT controller, which is connected to a battery. A dashed line labeled 'BYPASS' goes from the solar panel to a light bulb. A battery level indicator shows 100% and 25% marks.</p> |
| DC charging current / Battery voltage | <p>Charging current=25A, Battery voltage=56.0V</p>  <p>The LCD display shows '25 A' and '56.0 V'. Below the display is a schematic diagram showing a solar panel connected to an MPPT controller, which is connected to a battery. A dashed line labeled 'BYPASS' goes from the solar panel to a light bulb. A battery level indicator shows 100% and 25% marks.</p> |
| Battery voltage/ DC discharging current | <p>Battery voltage=53.0V, discharging current=1A</p>  <p>The LCD display shows '53.0 V' and '1 A'. Below the display is a schematic diagram showing a battery connected to a light bulb. A battery level indicator shows 100% and 25% marks.</p> |
| Main CPU version checking | <p>Main CPU version 00014.04</p>  <p>The LCD display shows '01 14 04'. Below the display is a schematic diagram showing a solar panel connected to an MPPT controller, which is connected to a battery. A dashed line labeled 'BYPASS' goes from the solar panel to a light bulb. A battery level indicator shows 100% and 25% marks.</p> |
| Secondary CPU version checking | <p>Secondary CPU version: 00003.03</p>  <p>The LCD display shows '02 03 03'. Below the display is a schematic diagram showing a solar panel connected to an MPPT controller, which is connected to a battery. A dashed line labeled 'BYPASS' goes from the solar panel to a light bulb. A battery level indicator shows 100% and 25% marks.</p> |












Operating Mode Description

| Operation mode | Description | LCD display |
|--|--|---|
| Standby mode Note: *Standby mode: The inverter is not turned on yet but at this time, the inverter can charge battery without AC output. | No output is supplied by the unit but it still can charge the batteries. | Charging by utility.  |
| | | Charging by PV energy.  |
| | | Charging by PV energy and utility  |
| | | No charging.  |
| Fault mode Note: *Fault mode: Errors are caused by internal circuit errors or external reasons such as over temperature, output short circuited and so on. | PV energy can charge the batteries. | Charging by PV energy.  |
| | | No charging.  |










| | | |
|--------------|--|---------------------------------------|
| Line Mode | The unit will provide output power from the mains. It will also charge the battery in line mode. | Charging by PV energy |
| | | Charging by utility. |
| | | Charging by PV energy and utility |
| Battery Mode | The unit will provide output power from battery and PV power. | Power from battery and PV energy. |
| | | Power from battery only. |

Fault Reference Code

| Fault Code | Fault Event | Icon on |
|------------|--|---------|
| 01 | Fan is locked when inverter is off. | |
| 02 | Over temperature | |
| 03 | Battery voltage is too high | |
| 04 | Battery voltage is too low | |
| 05 | Output short circuited or over temperature is detected by internal converter components. | |
| 06 | Output voltage is too high. | |
| 07 | Overload time out | |
| 08 | Bus voltage is too high | |
| 09 | Bus soft start failed | |
| 11 | Main relay failed | |

| | | |
|----|-----------------------------------|---|
| 51 | Over current or surge |  |
| 52 | Bus voltage is too low |  |
| 53 | Inverter soft start failed |  |
| 55 | Over DC voltage in AC output |  |
| 56 | Battery connection is open |  |
| 57 | Current sensor failed |  |
| 58 | Output voltage is too low |  |
| 87 | Internal circuit mismatch |  |
| 88 | Parallel ID missing |  |
| 89 | Parallel ID in conflict |  |
| 91 | Working mode synchronization loss |  |

Warning Indicator

| Warning Code | Warning Event | Audible Alarm | Icon flashing |
|--------------|---|-------------------------------|---|
| 01 | Fan is locked when inverter is on. | Beep three times every second |  |
| 03 | Battery is over-charged | Beep once every second |  |
| 04 | Low battery | Beep once every second |  |
| 07 | Overload | Beep once every 0.5 second |  |
| 10 | Output power derating | Beep twice every 3 seconds |  |
| 12 | Solar charger stops due to low battery. | |  |
| 13 | Solar charger stops due to high PV voltage. | |  |
| 14 | Solar charger stops due to overload. | |  |
| SL | Wrong wiring in LCD panel | |  |

SPECIFICATIONS

Table 1: Line Mode Specifications



| INVERTER MODEL | 5KVA |
|--|---|
| Input Voltage Waveform | Sinusoidal (utility or generator) |
| Nominal Input Voltage | 110/120Vac(L-N or L1-N-L2) |
| Low Loss Voltage | 95Vac \pm 7V (UPS) 65Vac \pm 7V (Appliances) |
| Low Loss Return Voltage | 100Vac \pm 7V (UPS); 70Vac \pm 7V (Appliances) |
| High Loss Voltage | 140Vac \pm 7V |
| High Loss Return Voltage | 135Vac \pm 7V |
| Max AC Input Voltage | 150Vac |
| Nominal Input Frequency | 50Hz / 60Hz (Auto-detection) |
| Low Loss Frequency | 40 \pm 1Hz |
| Low Loss Return Frequency | 42 \pm 1Hz |
| High Loss Frequency | 65 \pm 1Hz |
| High Loss Return Frequency | 63 \pm 1Hz |
| Output Short Circuit Protection | Line mode: Circuit Breaker Battery mode: Electronic Circuits |
| Max bypass current | 40A |
| Efficiency (Line Mode) | >95% (Rated R load, battery full charged) |
| Transfer Time (P1-N-P2) | 10ms typical, 12ms maximum @50Hz (UPS); 20ms typical, 25ms maximum @50Hz (Appliances) |
| Transfer Time (P-N) | 30ms @50Hz |
| Output power derating: When AC input voltage drops to 95V, the output power will be derated. | 120Vac model:  |

Table 2: Inverter Mode Specifications

| INVERTER MODEL | 5KVA |
|--|---|
| Rated Output Power | 5KVA/5KW |
| Output Voltage Waveform | Pure Sine Wave |
| Output Voltage Regulation | 110/120Vac(L-N or L1-N-L2) |
| Output Frequency | 60Hz or 50Hz |
| Peak Efficiency | 90% |
| Overload Protection | 5s@ $\geq 150\%$ load; 10s@110%~150% load |
| Surge Capacity | 2* rated power for 5 seconds |
| Nominal DC Input Voltage | 48Vdc |
| Cold Start Voltage | 46.0Vdc |
| Low DC Warning Voltage @ load < 20% @ 20% \leq load < 50% @ load \geq 50% | 44.0Vdc 42.8Vdc 40.4Vdc |
| Low DC Warning Return Voltage @ load < 20% @ 20% \leq load < 50% @ load \geq 50% | 46.0Vdc 44.8Vdc 42.4Vdc |
| Low DC Cut-off Voltage @ load < 20% @ 20% \leq load < 50% @ load \geq 50% | 42.0Vdc 40.8Vdc 38.4Vdc |
| High DC Recovery Voltage | 58Vdc |
| High DC Cut-off Voltage | 60Vdc |
| No Load Power Consumption | <100W |

Table 3: Charging Mode Specifications

| Utility Charging Mode | | |
|--|----------------------------|---------|
| INVERTER MODEL | 5KVA | |
| Charging Current (UPS) @ Nominal Input Voltage | 2A/10A/20A/30A/40A/50A/60A | |
| Bulk Charging Voltage | Flooded Battery | 58.4Vdc |
| | AGM / Gel Battery | 56.4Vdc |
| Floating Charging Voltage | 54Vdc | |
| Overcharge Protection | 60Vdc | |
| Charging Algorithm | 3-Step | |



| Solar Charging Mode(Per number of MPPT) | |
|---|-------------|
| INVERTER MODEL | 5KVA |
| Rated Power | 4000 W x 2 |
| Max. efficiency | 96% |
| Max. PV Array Open Voltage | 145Vdc |
| PV Array MPPT Voltage Range | 60~115Vdc |
| Min. battery voltage for PV charge | 34Vdc |
| Standby Power Consumption | <23W |
| Battery Voltage Accuracy | +/-0.3% |
| PV Voltage Accuracy | +/-2V |
| Charging Algorithm | 3-Step |
| Joint Utility and Solar Charging | |
| INVERTER MODEL | 5KVA |
| Max. Charging Current | 220A |
| Default Charging Current | 60Amp |

Table 4 General Specifications

| INVERTER MODEL | 5KVA |
|------------------------------------|---------------|
| Safety Certification | CE |
| Operating Temperature Range | -10°C to 50°C |
| Storage temperature | -15 °C~ 60 °C |
| Dimension (D*W*H), mm | 157*625*670 |
| Net Weight, kg | 26.4 |

TROUBLESHOOTING

| Problem | LCD/LED/Buzzer | Explanation / Possible cause | What to do |
|---|---|--|---|
| Unit shuts down automatically during startup process. | LCD/LEDs and buzzer will be active for 3 seconds and then completely off. | The battery voltage is too low (<1.91V/Cell) | 1. Re-charge the battery. 2. Replace the battery. |
| No response after power on. | No indication. | 1. The battery voltage is far too low. (<1.4V/Cell) 2. Battery polarity is connected reversely. | 1. Check if batteries and the wiring are connected well. 2. Re-charge the battery. 3. Replace the battery. |
| Mains exist but the unit works in battery mode. | Input voltage is displayed as 0 on the LCD and green LED is flashing. | Input protector is tripped | Check if AC breaker is tripped and AC wiring is connected well. |
| | Green LED is flashing. | Insufficient quality of AC power. (Shore or Generator) | 1. Check if AC wires are too thin and/or too long. 2. Check if generator (if applied) is working well or if the setting range of input voltage is correct. (UPS Appliance) |
| | Green LED is flashing. | Set "Solar First" as the priority of output source. | Change output source priority to Utility first. |
| When the unit is turned on, internal relay is switched on and off repeatedly. | LCD display and LEDs are flashing | Battery is disconnected. | Check if battery wires are connected well. |
| Buzzer beeps continuously and red LED is on. | Fault code 07 | Overload error. The inverter is overload by 110% and time is up. | Reduce the connected load by switching off some equipment. |
| | Fault code 05 | Output short circuited. | Check if wiring is connected well and remove abnormal load. |
| | | The temperature of internal converter is over 120°C. (Only available for 1-5KVA models.) | Check whether the air flow of the unit is blocked or whether the ambient temperature is too high. |
| | Fault code 02 | The internal temperature of the inverter is over 100°C. | |
| | Fault code 03 | Battery is over-charged. | Return to repair center. |
| | | The battery voltage is too high. | Check if spec and quantity of the batteries meet the requirements. |
| | Fault code 01 | Fan fault | Replace the fan. |
| | Fault code 06/58 | Output abnormal (Inverter voltage is lower than 190Vac or is higher than 260Vac) | 1. Reduce the connected load. 2. Return it to repair center |
| | Fault code 08/09/53/57 | Internal components failed. | Return it to repair center. |
| | Fault code 51 | Over current or surge. | Restart the unit, if the error happens again, please return it to repair center. |
| | Fault code 52 | Bus voltage is too low. | |
| | Fault code 55 | Output voltage is unbalanced. | |
| | Fault code 56 | Battery is not connected well or fuse is burnt. | If the battery is connected well, please return it to repair center. |

Appendix I: Approximate Back-up Time Table

| Model | Load (VA) | Backup Time @48Vdc 200Ah (min) | Backup Time @48Vdc 400Ah (min) |
|-------|-----------|--------------------------------|--------------------------------|
| 5KVA | 500 | 1226 | 2576 |
| | 1000 | 536 | 1226 |
| | 1500 | 316 | 804 |
| | 2000 | 222 | 542 |
| | 2500 | 180 | 430 |
| | 3000 | 152 | 364 |
| | 3500 | 130 | 282 |
| | 4000 | 100 | 224 |
| | 4500 | 88 | 200 |
| | 5000 | 80 | 180 |

Note: Backup time depends on the quality of the battery, age of battery and type of battery.
Specifications of batteries may vary depending on different manufacturers.

Appendix II: Parallel function

1. Introduction

This inverter can be used in parallel with three different operation modes.

1. Parallel operation in single phase with up to three units. The supported maximum output power is 15KW/15KVA.
2. Maximum three units work together to support three-phase equipment. The supported maximum output power is 15KW/15KVA.
3. Maximum three units work together to support two-phase equipment. One units support two phase. The supported maximum output power is 15KW/15KVA and one phase can be up to 7.5KW/7.5KVA.

2. Package Contents

In parallel kit, you will find the following items in the package:




Parallel communication cable



Current sharing cable

3. Mounting the Unit

When installing multiple units, please follow the illustration below.



NOTE: For proper air circulation to dissipate heat, allow a clearance of approx. 20 cm to the side and approx. 50 cm above and below the unit. Be sure to install each unit in the same height.

4. Wiring Connection

The size of the cable for each inverter is shown as below:

WARNING: Be sure the length of all battery cables is the same. Otherwise, there will be voltage difference between inverter and battery which might cause mal-function of the parallel inverters.

Recommended battery cable and terminal size for each inverter:

| Model | Wire Size | Torque value |
|-------|-----------|--------------|
| 5KVA | 2*4AWG | 5~ 6 Nm |

Recommended cable size of AC input and output for each inverter:

| Model | AWG no. | Torque |
|-------|---------|-----------|
| 5KVA | 10 AWG | 1.4~1.6Nm |

You need to connect the cables of each inverter together. Take the battery cables for example: You need to use a connector or bus-bar as a joint to connect the battery cables together, and then connect it to the battery terminal. The size of the cable used from joint to battery should be X times cable size in the tables above. X''' indicates the number of inverters connected in parallel.

Regarding AC input and output, please also follow the same principle.

WARNING! Please make sure all output N wires of each inverter must be connected always. Otherwise, it will cause inverter fault in error code # 72.

CAUTION!! Please install the breaker at the battery and AC input side. This will ensure the inverter can be securely disconnected during maintenance and fully protected from over current of battery or AC input. The recommended mounted location of the breakers is shown in the parallel diagrams in section 5-1 and 5-2.

Recommended specification of battery breaker for each inverter:

| Model | 1 unit* |
|-------|------------|
| 5KVA | 125A/80VDC |

*If you want to use only one breaker at the battery side for the whole system, the rating of the breaker should be X times current of 1 unit. X'' indicates the number of inverters connected in parallel.

Recommended specification of AC input breaker in single phase:

| Model | 2 units | 3 units |
|-------|------------|-------------|
| 5KVA | 80A/230VAC | 120A/230VAC |

Note 1: You also can use only one 40A breaker for each inverter at its AC input.

Note 2: Regarding three-phase system, you can use 3-pole breaker directly and the rating of the breaker should be compatible with the phase current limitation from the phase with maximum units.


Recommended battery capacity

| Inverter parallel numbers | 2 | 3 |
|---------------------------|-------|-------|
| Battery Capacity | 400AH | 600AH |

WARNING! Be sure that all inverters will share the same battery bank. Otherwise, the inverters will be transferred to fault mode.

5. Parallel ID Setting

It's necessary to set up parallel ID for each inverter.











| 1 | 2 | 3 | 4 | Parallel ID |
|-----|-----|-----|---|-------------|
| OFF | OFF | OFF | * | 0 |
| ON | OFF | OFF | * | 1 |
| OFF | ON | OFF | * | 2 |
| ON | ON | OFF | * | 3 |
| OFF | OFF | ON | * | 4 |
| ON | OFF | ON | * | 5 |
| OFF | ON | ON | * | 6 |
| ON | ON | ON | * | 7 |

* Not used











6. LCD Setting and Display

Setting Program:

| Program | Description | Selectable option |
|---------|--|---|
| 28 | AC output mode *This setting is only available when the inverter is in standby mode (Switch off). | <p>Parallel output in single phase. Output voltage is 120V.</p>  <p>When the units are used in parallel for single phase application, please select "2A0" in program 28. L1 to L2 out voltage is 0V and L to N output voltage is 120V. Please refers to 7-1 for detailed wiring.</p> |
| | | <p>Support L1 phase output on 3-Phase application. Output voltage is 120V.</p>  <p>It is required to have at least 3 inverters to support three-phase equipment. It's required to have at least one inverter in each phase or it's up to four inverters in one phase. Please refers to 7-3 for detailed information.</p> |
| | | <p>Support L2 phase output on 3-Phase application. Output voltage is 120V.</p>  <p>Please select "3P1" in program 28 for the inverters connected to L1 phase, "3P2" in program 28 for the inverters connected to L2 phase and "3P3" in program 28 for the inverters connected to L3 phase.</p> |
| | | <p>Support L3 phase output on 3-Phase application. Output voltage is 120V.</p>  <p>Be sure to connect shared current cables to units in the same phase. Do NOT connect shared current cables between units in different phases.</p> |
| | | <p>Support L1/L2 phase output on split phase application with L1 to L2 output voltage in 208V.</p>  <p>When the units are used in parallel for split phase application, please select "2A1" or "2A2" in program 28. "2A1" is selected, L1 to L2 output voltage is 208V and L to N output voltage is 120V.</p> |
| | | <p>Support L1/L2 phase output on split phase application with L1 to L2 output voltage in 240V.</p>  <p>When "2A2" is selected, L1 to L2 output voltage is 240V and L to N output voltage is 120V. Please refers to 7-2 for detailed wiring.</p> |

| | | | |
|----|---|--|---|
| 30 | PV judge condition (Only apply for setting "Solar first" in program 1: Output source priority) | One Inverter (Default):  | When "ONE" is selected, as long as one of the inverters has been connected to PV modules and PV input is normal, parallel or 3-phase system will continue working according to rule of "solar first" setting. For example, two units are connected in parallel and set "SOL" in output source priority. If one of the two units has connected to PV modules and PV input is normal, the parallel system will provide power to loads from solar or battery power. If both of them are not sufficient, the system will provide power to loads from utility. |
| | | All of Inverters:  | When "ALL" is selected, parallel or 3-phase system will continue working according to rule of "solar first" setting only when all of inverters are connected to PV modules. For example, two units are connected in parallel and set "SOL" in output source priority. When "ALL" is selected in program 30, it's necessary to have all inverters connected to PV modules and PV input is normal to allow the system to provide power to loads from solar and battery power. Otherwise, the system will provide power to loads from utility. |

Fault code:

| Fault Code | Fault Event | Icon on |
|------------|---|---|
| 60 | Power feedback protection |  |
| 71 | Firmware version inconsistent |  |
| 72 | Current sharing fault |  |
| 80 | CAN fault |  |
| 81 | Host loss |  |
| 82 | Synchronization loss |  |
| 83 | Battery voltage detected different |  |
| 84 | Different AC input voltage and frequency detected |  |
| 85 | AC output current unbalance |  |
| 86 | AC output mode setting is different |  |

7. Commissioning

Parallel in single phase

Step 1: Check the following requirements before installation:


Correct wire connection

Ensure all breakers in Line wires at load side are open and each Neutral wires of each unit is connected together.


Step 2: Turn on all of the units and configure LCD program 28 as 2A0. And then shut down all units.

NOTE: It's necessary to turn off switch when setting LCD program. Otherwise, the setting cannot be programmed. All the units must use same selection.

Step 3: Turn on each unit.



Step 4: Switch on all AC breakers of Line wires in AC input. It's better to connect all of the inverters to the utility at the same time. If not, it will display fault 82 in the following inverters. However, these inverters will automatically restart. If detecting AC connection, they will work normally.



Step 5: If there is no more fault alarm, the parallel system is completely installed.

Step 6: Please switch on all breakers of Line wires in load side. This system will start to provide power to the load.

Parallel in split phase

Step 1: Check the following requirements before installation:


Correct wire connection

Ensure all breakers in Line wires at load side are open and each Neutral wires of each unit is connected together.


Step 2: Turn on all of the units and configure LCD program 28 as 2A1 or 2A2. And then shut down all units.

NOTE: It's necessary to turn off switch when setting LCD program. Otherwise, the setting cannot be programmed. All the units must use same selection.

Step 3: Turn on each unit.



Step 4: Switch on all AC breakers of Line wires in AC input. It's better to connect all of the inverters to the utility at the same time. If not, it will display fault 82 in the following inverters. However, these inverters will automatically restart. If detecting AC connection, they will work normally.



Step 5: If there is no more fault alarm, the parallel system is completely installed.

Step 6: Please switch on all breakers of Line wires in load side. This system will start to provide power to the load.

Support three-phase equipment

Step 1: Check the following requirements before installation:




Correct wire connection


Ensure all breakers in Line wires at load side are open and each Neutral wires of each unit is connected together.




Step 2: Turn on all of the units and configure LCD program 28 as 3P1, 3P2 and 3P3 sequentially. And then shut down all units.

NOTE: It's necessary to turn off switch when setting LCD program. Otherwise, the setting can not be programmed.

Step 3: Turn on all units sequentially.

| LCD display in L1-phase unit | LCD display in L2-phase unit | LCD display in L3-phase unit |
|---|--|---|
|  |  |  |

Step 4: Switch on all AC breakers of Line wires in AC input. If AC connection is detected and three phases are matched with unit setting, they will work normally. Otherwise, the AC icon  will flash and they will not work in line mode. Under this circumstance, you can switch wires of AC inputs from L2 phase and L3 phase. Or you may exchange the LCD program 28 of P2 and P3 to solve this problem.

| LCD display in L1-phase unit | LCD display in L2-phase unit | LCD display in L3-phase unit |
|---|--|---|
|  |  |  |

Step 5: If there is no more fault alarm, the system to support 3-phase equipment is completely installed.

Step 6: Please switch on all breakers of Line wires in load side. This system will start to provide power to the load.


Note 1: To avoid overload occurring, before turning on breakers at load side, it's better to have the whole system in operation first.

Note 2: There is some transfer time for this operation. Power interruption may happen to critical devices, which cannot tolerate transfer time.


7-1. Parallel Operation in Single phase

Two inverters in parallel:

Power Connection




Communication Connection



Three inverters in parallel:

Power Connection




Communication Connection




7-2. Support 2-phase equipment

Two inverters in parallel (Line to Line output voltage is 208V):

Power Connection




Communication Connection




Two inverters in parallel (Line to Line output voltage is 240V):

Power Connection




Communication Connection




Three inverters in parallel (Line to Line output voltage is 208V):

Power Connection




Communication Connection




Three inverters in parallel (Line to Line output voltage is 240V):

Power Connection




Communication Connection




7-3. Support 3-phase equipment

One inverter in each phase:

Power Connection



Communication Connection



WARNING: Do NOT connect the current sharing cables between the inverters in different phases. Otherwise, it may damage the inverters.

NOTE: For parallel model operation, please refer to LCD program 28

8. PV Connection

Please refer to the user manual of single unit for PV Connection.

CAUTION: Each inverter should connect to PV modules separately.

9. Troubleshooting

If the device fails to function as expected, check the list of common faults below before consulting the service center.

| Situation | | Solution |
|------------|--|---|
| Fault Code | Fault Event Description | |
| 60 | Current feedback into the inverter is detected. | <ol style="list-style-type: none"> 1. Restart the inverter. 2. Check if L/N cables are not connected reversely in all inverters. 3. For parallel system in single phase, make sure the current sharing cables are connected to all inverters. For supporting three-phase system, make sure the current sharing cables are connected to the inverters in the same phase, and disconnected to the inverters in different phases. 4. If the problem remains, please contact your installer. |
| 71 | The firmware version of each inverter is not the same. | <ol style="list-style-type: none"> 1. Update the firmware of all inverter to the same version. 2. Check the version of each inverter via LCD setting and make sure the CPU versions are the same. If not, please contact your installer to provide the latest firmware to update. 3. After updating, if the problem still remains, please contact your installer. |
| 72 | The output current of each inverter is different. | <ol style="list-style-type: none"> 1. Check if shared cables are connected well and restart the inverter. 2. If the problem remains, please contact your installer. |
| 80 | CAN data loss | <ol style="list-style-type: none"> 1. Check if communication cables are connected well and restart the inverter. 2. If the problem remains, please contact your installer. |
| 81 | Host data loss | |
| 82 | Synchronization data loss | |
| 83 | The battery voltage of each inverter is not the same. | <ol style="list-style-type: none"> 1. Make sure all inverters share the same groups of batteries together. 2. Remove all loads and disconnect AC input and PV input. Then, check battery voltage of all inverters. If the values from all inverters are close, please check if all battery cables are in the same length and in the same material type. Otherwise, please contact your installer to provide SOP to calibrate battery voltage of each inverter. 3. If the problem still remains, please contact your installer. |
| 84 | AC input voltage and frequency are detected different. | <ol style="list-style-type: none"> 1. Check the utility wiring connection and restart the inverter. 2. Make sure utility starts up at same time. If there are breakers installed between utility and inverters, please be sure all AC input breakers can be turned on at same time. 3. If the problem remains, please contact your installer. |
| 85 | AC output current unbalance | <ol style="list-style-type: none"> 1. Restart the inverter. 2. Remove some excessive loads and re-check the load information from LCD of the inverters. If the values are different, please check if AC input and output cables are in the same length and in the same material type. 3. If the problem remains, please contact your installer. |
| 86 | AC output mode setting is different. | <ol style="list-style-type: none"> 1. Switch off the inverter and check LCD setting #28. 2. For parallel system in single phase application, make sure no 2A1, 2A2, 3P1, 3P2 or 3P3 is set on #28. For parallel system in split phase application, make sure no 2A0, 3P1, 3P2 or 3P3 is set on #28. Check #28 LCD setting section for the correct output voltage setting. For supporting three-phase system, make sure no 2A0, 2A1 or 2A2 is set on #28. 3. If the problem remains, please contact your installer. |